DTC TABLE [DSC HU/CM]

id040262985200

×: Applicable
—: Not applicable

DTC	ABS warning light	Brake system warning light (when parking brake is released)	TCS/ DSC indicator light	DSC OFF indicator light	Tire Pressure Monitoring System (TPMS) warning light*1	Smart City Brake Support (SCBS) warning light (amber)*2	Description	Fail-safe	Drive cycle	Self test type*3	Memory function	Page
B10DF:46	Not illuminate	Not illuminate	Illuminates	Not illuminate	Not illuminate	Illuminates	DSC HU/CM internal malfunction	×	—	C, D	×	(See DTC B10DF:46/ C1A08:1C/ U2007:46/ U2007:62/ U3000:49 [DSC HU/ CM].)
B11D4:08	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Illuminates	Laser sensor	×	—	C, D	×	(See DTC B11D4:08 [DSC HU/ CM].)
C0001:01 C0002:01 C0003:01 C0004:01 C0010:01 C0011:01 C0014:01 C0015:01 C0018:01 C0019:01 C001C:01 C001D:01	Illuminates	Illuminates	Illuminates	Not illuminate	Not illuminate	Illuminates	DSC HU/CM internal malfunction (solenoid valve system)	×	—	C, D	×	(See DTC C0001:01/ C0002:01/ C0003:01/ C0004:01/ C0010:01/ C0011:01/ C0014:01/ C0015:01/ C0018:01/ C0019:01/ C001C:01/ C001D:01 [DSC HU/ CM].)
C0020:11 C0020:12 C0020:13 C0020:71	Illuminates	Not illuminate	Illuminates	Not illuminate	Not illuminate	Illuminates	Pump motor, motor relay	×	—	C, D	×	(See DTC C0020:11/ C0020:12/ C0020:13/ C0020:71 [DSC HU/ CM].)
C0023:62	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Illuminates	Brake switch	×	—	C, D	×	(See DTC C0023:62/ C0040:64 [DSC HU/ CM].)

DTC	ABS warning light	Brake system warning light (when parking brake is released)	TCS/ DSC indicator light	DSC OFF indicator light	Tire Pressure Monitoring System (TPMS) warning light*1	Smart City Brake Support (SCBS) warning light (amber)*2	Description	Fail-safe	Drive cycle	Self test type*3	Memory function	Page
C0030:07	Illuminates	Not illuminate*4	Illuminates	Not illuminate	Illuminates	Illuminates	LF ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/ C003A:07/ C003A:29/ C003A:2F/ C003A:64 [DSC HU/ CM].)
C0031:07							LF ABS wheel-speed sensor/ABS sensor rotor					
C0031:11	Illuminates	Not illuminate*4	Illuminates	Not illuminate	Illuminates	Illuminates	LF ABS wheel-speed sensor	×	—	C, D	×	(See DTC C0031:11/ C0031:15/ C0034:11/ C0034:15/ C0037:11/ C0037:15/ C003A:11/ C003A:15 [DSC HU/ CM].)
C0031:15												

DTC	ABS warning light	Brake system warning light (when parking brake is released)	TCS/ DSC indicator light	DSC OFF indicator light	Tire Pressure Monitoring System (TPMS) warning light*1	Smart City Brake Support (SCBS) warning light (amber)*2	Description	Fail-safe	Drive cycle	Self test type*3	Memory function	Page
C0031:29 C0031:2F C0031:64	Illuminates	Not illuminate*4	Illuminates	Not illuminate	Illuminates	Illuminates	LF ABS wheel-speed sensor/ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/ C003A:07/ C003A:29/ C003A:2F/ C003A:64 [DSC HU/ CM].)
C0033:07 C0034:07	Illuminates	Not illuminate*4	Illuminates	Not illuminate	Illuminates	Illuminates	RF ABS sensor rotor RF ABS wheel-speed sensor/ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/ C003A:07/ C003A:29/ C003A:2F/ C003A:64 [DSC HU/ CM].)

DTC	ABS warning light	Brake system warning light (when parking brake is released)	TCS/ DSC indicator light	DSC OFF indicator light	Tire Pressure Monitoring System (TPMS) warning light*1	Smart City Brake Support (SCBS) warning light (amber)*2	Description	Fail-safe	Drive cycle	Self test type*3	Memory function	Page
C0034:11 C0034:15	Illuminates	Not illuminate*4	Illuminates	Not illuminate	Illuminates	Illuminates	RF ABS wheel-speed sensor	×	—	C, D	×	(See DTC C0031:11/ C0031:15/ C0034:11/ C0034:15/ C0037:11/ C0037:15/ C003A:11/ C003A:15 [DSC HU/ CM].)
C0034:29 C0034:2F C0034:64	Illuminates	Not illuminate*4	Illuminates	Not illuminate	Illuminates	Illuminates	RF ABS wheel-speed sensor/ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/ C003A:07/ C003A:29/ C003A:2F/ C003A:64 [DSC HU/ CM].)

DTC	ABS warning light	Brake system warning light (when parking brake is released)	TCS/ DSC indicator light	DSC OFF indicator light	Tire Pressure Monitoring System (TPMS) warning light*1	Smart City Brake Support (SCBS) warning light (amber)*2	Description	Fail-safe	Drive cycle	Self test type*3	Memory function	Page
C0036:07	Illuminates	Not illuminate*4	Illuminates	Not illuminate	Illuminates	Illuminates	LR ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/ C003A:07/ C003A:29/ C003A:2F/ C003A:64 [DSC HU/ CM].)
C0037:07							LR ABS wheel-speed sensor/ABS sensor rotor					
C0037:11	Illuminates	Not illuminate*4	Illuminates	Not illuminate	Illuminates	Illuminates	LR ABS wheel-speed sensor	×	—	C, D	×	(See DTC C0031:11/ C0031:15/ C0034:11/ C0034:15/ C0037:11/ C0037:15/ C003A:11/ C003A:15 [DSC HU/ CM].)
C0037:15												

DTC	ABS warning light	Brake system warning light (when parking brake is released)	TCS/ DSC indicator light	DSC OFF indicator light	Tire Pressure Monitoring System (TPMS) warning light*1	Smart City Brake Support (SCBS) warning light (amber)*2	Description	Fail-safe	Drive cycle	Self test type*3	Memory function	Page
C0037:29 C0037:2F C0037:64	Illuminates	Not illuminate*4	Illuminates	Not illuminate	Illuminates	Illuminates	LR ABS wheel-speed sensor/ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/ C003A:07/ C003A:29/ C003A:2F/ C003A:64 [DSC HU/ CM].)
C0039:07 C003A:07	Illuminates	Not illuminate*4	Illuminates	Not illuminate	Illuminates	Illuminates	RR ABS sensor rotor RR ABS wheel-speed sensor/ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/ C003A:07/ C003A:29/ C003A:2F/ C003A:64 [DSC HU/ CM].)

DTC	ABS warning light	Brake system warning light (when parking brake is released)	TCS/ DSC indicator light	DSC OFF indicator light	Tire Pressure Monitoring System (TPMS) warning light*1	Smart City Brake Support (SCBS) warning light (amber)*2	Description	Fail-safe	Drive cycle	Self test type*3	Memory function	Page
C003A:11 C003A:15	Illuminates	Not illuminate*4	Illuminates	Not illuminate	Illuminates	Illuminates	RR ABS wheel-speed sensor	×	—	C, D	×	(See DTC C0031:11/ C0031:15/ C0034:11/ C0034:15/ C0037:11/ C0037:15/ C003A:11/ C003A:15 [DSC HU/ CM].)
C003A:29 C003A:2F C003A:64	Illuminates	Not illuminate*4	Illuminates	Not illuminate	Illuminates	Illuminates	RR ABS wheel-speed sensor/ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/ C003A:07/ C003A:29/ C003A:2F/ C003A:64 [DSC HU/ CM].)
C0040:64	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	Brake switch	×	—	C, D	×	(See DTC C0023:62/ C0040:64 [DSC HU/ CM].)
C0044:28 C0044:47 C0044:49 C0044:51	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates*5	Illuminates*5	Brake fluid pressure sensor	×	—	C, D	×	(See DTC C0044:28/ C0044:47/ C0044:49/ C0044:51/ C0044:54/ C0044:64/ C0044:8F [DSC HU/ CM].)
C0044:54	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates						
C0044:64 C0044:8F	Illuminates	Illuminates	Illuminates	Not illuminate	Illuminates	Illuminates						

DTC	ABS warning light	Brake system warning light (when parking brake is released)	TCS/ DSC indicator light	DSC OFF indicator light	Tire Pressure Monitoring System (TPMS) warning light*1	Smart City Brake Support (SCBS) warning light (amber)*2	Description	Fail-safe	Drive cycle	Self test type*3	Memory function	Page
C0051:62	Illuminates	Illuminates	Illuminates	Not illuminate	Illuminates	Illuminates	EPS control module	×	—	C, D	×	(See DTC C0051:62/ C0051:64/ C0051:67/ C0051:85 [DSC HU/ CM].)
C0051:64												
C0051:67	Not illuminate	Not illuminate	Illuminates	Not illuminate	Not illuminate	Illuminates						
C0051:85	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates						
C0061:28	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	SAS control module	×	—	C, D	×	(See DTC C0061:28/ C0061:64/ C0062:28/ C0062:64/ C0063:28/ C0063:64 [DSC HU/ CM].)
C0061:54	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	DSC HU/CM (unperformed initialization procedure)	×	—	C, D	×	(See DTC C0061:54/ C0062:54/ C0063:54 [DSC HU/ CM].)
C0061:64	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	SAS control module	×	—	C, D	×	(See DTC C0061:28/ C0061:64/ C0062:28/ C0062:64/ C0063:28/ C0063:64 [DSC HU/ CM].)
C0062:28	Not illuminate	Not illuminate	Illuminates	Not illuminate	Not illuminate	Not illuminate			—			
C0062:54	Not illuminate	Not illuminate	Illuminates	Not illuminate	Not illuminate	Not illuminate	DSC HU/CM (unperformed initialization procedure)	×	—	C, D	×	(See DTC C0061:54/ C0062:54/ C0063:54 [DSC HU/ CM].)
C0062:64	Not illuminate	Not illuminate	Illuminates	Not illuminate	Not illuminate	Not illuminate	SAS control module	×	—	C, D	×	(See DTC C0061:28/ C0061:64/ C0062:28/ C0062:64/ C0063:28/ C0063:64 [DSC HU/ CM].)
C0062:76	Not illuminate	Not illuminate	Illuminates	Not illuminate	Not illuminate	Not illuminate	SAS control module	×	—	C, D	×	(See DTC C0062:76 [DSC HU/ CM].)

DTC	ABS warning light	Brake system warning light (when parking brake is released)	TCS/ DSC indicator light	DSC OFF indicator light	Tire Pressure Monitoring System (TPMS) warning light*1	Smart City Brake Support (SCBS) warning light (amber)*2	Description	Fail-safe	Drive cycle	Self test type*3	Memory function	Page
C0063:28	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	SAS control module	×	—	C, D	×	(See DTC C0061:28/ C0061:64/ C0062:28/ C0062:64/ C0063:28/ C0063:64 [DSC HU/ CM].)
C0063:54	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	DSC HU/CM (unperformed initialization procedure)	×	—	C, D	×	(See DTC C0061:54/ C0062:54/ C0063:54 [DSC HU/ CM].)
C0063:64	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	SAS control module	×	—	C, D	×	(See DTC C0061:28/ C0061:64/ C0062:28/ C0062:64/ C0063:28/ C0063:64 [DSC HU/ CM].)
C006B:00	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	TCS/DSC control	×	—	C, D	×	(See DTC C006B:00/ C0072:68 [DSC HU/ CM].)
C0072:68			Not illuminate		Not illuminate	Not illuminate			—			
C1031:35	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Illuminates	Not illuminate	Tire Pressure Monitoring System (TPMS) set switch	×	—	C, D	×	(See DTC C1031:35 [DSC HU/ CM].)
C1031:41	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Illuminates	Not illuminate	Tire Pressure Monitoring System (TPMS)	×	—	C, D	×	(See DTC C1031:41 [DSC HU/ CM].)
C1031:54												(See DTC C1031:54 [DSC HU/ CM].)
C1031:68												(See DTC C1031:68 [DSC HU/ CM].)
C1109:64	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Not illuminate	DSC OFF switch	—	—	C, D	×	(See DTC C1109:64 [DSC HU/ CM].)

DTC	ABS warning light	Brake system warning light (when parking brake is released)	TCS/ DSC indicator light	DSC OFF indicator light	Tire Pressure Monitoring System (TPMS) warning light*1	Smart City Brake Support (SCBS) warning light (amber)*2	Description	Fail-safe	Drive cycle	Self test type*3	Memory function	Page
C1A08:1C	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	DSC HU/CM internal malfunction	×	—	C, D	×	(See DTC B10DF:46/ C1A08:1C/ U2007:46/ U2007:62/ U3000:49 [DSC HU/ CM].)
P0942:46	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	DSC HU/CM mismatched installation	×	—	C, D	×	(See DTC P0942:46/ P0942:49 [DSC HU/ CM].)
P0942:49	Illuminates*5	Illuminates*5	Illuminates	Not illuminate	Illuminates	Illuminates			—			
U0001:88	Illuminates	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	CAN line	×	—	C, D	×	(See DTC U0001:88/ U0100:00/ U0101:00/ U0131:00/ U0151:00/ U0155:00/ U0235:00 [DSC HU/ CM].)
U0100:00	Illuminates*5	Not illuminate	Illuminates*5	Not illuminate	Illuminates*5	Illuminates*5						
U0101:00	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates						
U0131:00	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates						
U0151:00	Not illuminate	Not illuminate	Illuminates	Not illuminate	Not illuminate	Illuminates*5						
U0155:00	Illuminates*5	Not illuminate	Illuminates*5	Not illuminate	Not illuminate	Illuminates*5						
U0235:00	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Illuminates						
U0336:00	Not illuminate	Not illuminate	Illuminates	Not illuminate	Not illuminate	Not illuminate	Signal error from SAS control module	×	—	C, D	×	(See DTC U0336:00 [DSC HU/ CM].)
U0401:00	Not illuminate	Not illuminate	Illuminates*5	Not illuminate	Illuminates*5	Illuminates*5	Signal error from PCM	×	—	C, D	×	(See DTC U0401:00 [DSC HU/ CM].)
U0402:00	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	Signal error from transmission /transaxle	×	—	C, D	×	(See DTC U0402:00 [DSC HU/ CM].)
U0420:00	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	Signal error from EPS control module	×	—	C, D	×	(See DTC U0420:00 [DSC HU/ CM].)

DTC	ABS warning light	Brake system warning light (when parking brake is released)	TCS/ DSC indicator light	DSC OFF indicator light	Tire Pressure Monitoring System (TPMS) warning light*1	Smart City Brake Support (SCBS) warning light (amber)*2	Description	Fail-safe	Drive cycle	Self test type*3	Memory function	Page
U0423:00	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Illuminates	Illuminates	Signal error from instrument cluster	×	—	C, D	×	(See DTC U0423:00/ U0443:00 [DSC HU/ CM].)
U0433:00	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Illuminates	Signal error from laser sensor	×	—	C, D	×	(See DTC U0433:00 [DSC HU/ CM].)
U0443:00	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Illuminates	Signal error from instrument cluster	×	—	C, D	×	(See DTC U0423:00/ U0443:00 [DSC HU/ CM].)
U0452:86	Not illuminate	Not illuminate	Illuminates	Not illuminate	Illuminates*5	Illuminates*5	Signal error from SAS control module	×	—	C, D	×	(See DTC U0452:86 [DSC HU/ CM].)
U2007:46	Not illuminate	Not illuminate	Illuminates	Not illuminate	Not illuminate	Illuminates	DSC HU/CM internal malfunction	×	—	C, D	×	(See DTC B10DF:46/ C1A08:1C/ U2007:46/ U2007:62/ U3000:49 [DSC HU/ CM].)
U2007:62	Illuminates	Illuminates	Illuminates	Not illuminate	Not illuminate	Illuminates	DSC HU/CM internal malfunction	×	—	C, D	×	(See DTC B10DF:46/ C1A08:1C/ U2007:46/ U2007:62/ U3000:49 [DSC HU/ CM].)
U2101:00 U2300:52 U2300:54 U2300:55 U2300:56 U2300:64	Illuminates	Not illuminate	Illuminates	Not illuminate	Illuminates	Illuminates	DSC HU/CM configuration	×	—	C, D	×	(See DTC U2101:00/ U2300:52/ U2300:54/ U2300:55/ U2300:56/ U2300:64 [DSC HU/ CM].)
U3000:49	Illuminates	Illuminates*5	Illuminates	Not illuminate	Illuminates	Illuminates	DSC HU/CM internal malfunction	×	—	C, D	×	(See DTC B10DF:46/ C1A08:1C/ U2007:46/ U2007:62/ U3000:49 [DSC HU/ CM].)

DTC	ABS warning light	Brake system warning light (when parking brake is released)	TCS/ DSC indicator light	DSC OFF indicator light	Tire Pressure Monitoring System (TPMS) warning light*1	Smart City Brake Support (SCBS) warning light (amber)*2	Description	Fail-safe	Drive cycle	Self test type*3	Memory function	Page
U3003:08	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Not illuminate	Battery power supply	—	—	C, D	×	(See DTC U3003:08/ U3003:16/ U3003:17 [DSC HU/ CM].)
U3003:16	Illuminates	Not illuminate*6	Illuminates	Not illuminate	Illuminates	Illuminates		×				
		Illuminates*7 *8										
U3003:17	Illuminates	Illuminates	Illuminates	Not illuminate	Illuminates	Illuminates						

*1 : With Tire Pressure Monitoring System (TPMS)
*2 : With Smart City Brake Support (SCBS)
*3 : C: CMDTC self test, D: ODDTC self test
*4 : Illuminates when two wheels or more have a malfunction
*5 : Not illuminate depending on malfunction content
*6 : When power supply voltage is 7.9—9.6 V for 0.7 s or more
*7 : When power supply voltage is 6.0—7.9 V for 0.8 s or more
*8 : When power supply voltage is 6 V or less for 0.05 s or more

Fail-safe function table

×: Control enabled
—: Control disabled

DTC	ABS control	EBD control	TCS control		DSC control	Brake assist control	Vehicle roll prevention function control*1	Hill Launch Assist (HLA) control	Tire pressure monitoring system (TPMS) control*2	Smart City Brake Support (SCBS) control*3	Secondary Collision Reduction (SCR) control*3
			Brake control	Engine control							
B10DF:46	×	×	—		—	—	—	—	×	—	—
B11D4:08	×	×	×		×	×	×	×	×	×	×
C0001:01	—	—	—		—	—	—	—	×	—	—
C0002:01											
C0003:01											
C0004:01											
C0010:01											
C0011:01											
C0014:01											
C0015:01											
C0018:01											
C0019:01											
C001C:01											
C001D:01											

DTC	ABS control	EBD control	TCS control		DSC control	Brake assist control	Vehicle roll prevention function control*1	Hill Launch Assist (HLA) control	Tire pressure monitoring system (TPMS) control*2	Smart City Brake Support (SCBS) control*3	Secondary Collision Reduction (SCR) control*3
			Brake control	Engine control							
C0020:11 C0020:12 C0020:13 C0020:71	—	×	—		—	—	—	—	×	—	—
C0023:62	×	×	×		×	×	×	×	×	—	×
C0030:07 C0031:07 C0031:11 C0031:15 C0031:29 C0031:2F C0031:64	—	×*4	—		—	—	—	—	—	—	—
C0033:07 C0034:07 C0034:11 C0034:15 C0034:29 C0034:2F C0034:64	—	×*4	—		—	—	—	—	—	—	—
C0036:07 C0037:07 C0037:11 C0037:15 C0037:29 C0037:2F C0037:64	—	×*4	—		—	—	—	—	—	—	—
C0039:07 C003A:07 C003A:11 C003A:15 C003A:29 C003A:2F C003A:64	—	×*4	—		—	—	—	—	—	—	—
C0040:64	×	×	×		×	—	—	—	—	—	×
C0044:28 C0044:47 C0044:49 C0044:51	×	×	—*5		—*5	—	—*5	—*5	—*5	—*5	—*5
C0044:54	×	×	—		—	—	—	—	—	—	—
C0044:64 C0044:8F	×	×	—		—	—	—	—	—	—	—
C0051:62 C0051:64	×	×	—		—	×	×	×	—	—	—
C0051:67	×	×	—		—	×	×	×	×	—	—
C0051:85	×	×	—		—	×	×	×	—	—	—
C0061:28	×	×	—		—	×	×	×	—	—	—
C0061:54	×	×	—		—	×	×	×	—	—	—
C0061:64	×	×	—		—	×	×	×	—	—	—
C0062:28 C0062:54 C0062:64 C0062:76	×	×	×		×	×	—	—	×	×	×
C0063:28	×	×	—		—	×	×	×	—	—	—
C0063:54	×	×	—		—	×	×	×	—	—	—

DTC	ABS control	EBD control	TCS control		DSC control	Brake assist control	Vehicle roll prevention function control*1	Hill Launch Assist (HLA) control	Tire pressure monitoring system (TPMS) control*2	Smart City Brake Support (SCBS) control*3	Secondary Collision Reduction (SCR) control*3
			Brake control	Engine control							
C0063:64	×	×	—		—	×	×	×	—	—	—
C006B:00	×	×	—		—	×	×	×	—	—	—
C0072:68	×	×	—	×	×	×	×	×	×	×	×
C1031:35 C1031:41 C1031:54 C1031:68	×	×	×		×	×	×	×	—	×	×
C1109:64	×	×	×		×	×	×	×	×	×	×
C1A08:1C	×	×	—		—	—	—	—	—	—	—
P0942:46	×	×	—		—	—	—	—	—	—	—
P0942:49	—*5	—*5	—		—	—	—	—	—	—	—
U0001:88	—	×	—		—	—	—	—	—	—	—
U0100:00	—*5	×	—*5		—*5	—*5	—*5	—*5	—*5	—*5	—*5
U0101:00	×	×	—		—	×	—*5	—*5	—	—	—
U0131:00	×	×	—		—	×	×	×	—	—	—
U0151:00	×	×	—*5		—*5	—*5	—*5	—*5	×	—*5	—*5
U0155:00	—*5	×	—*5		—*5	—*5	—*5	—*5	×	—*5	—*5
U0235:00	×	×	×		×	×	×	×	×	—	×
U0336:00	×	×	×		×	×	×	×	×	×	—
U0401:00	×	×	—*5		—*5	×	—*5	—*5	—*5	—*5	—*5
U0402:00	×	×	—		—	×	—	—	—	—	—
U0420:00	×	×	—		—	×	×	×	—	—	—
U0423:00	×	×	×		×	×	×	×	—	—	×
U0433:00	×	×	×		×	×	×	×	×	—	×
U0443:00	×	×	×		×	×	×	×	×	—	×
U0452:86	×	×	—*5		—*5	×	—*5	—*5	—*5	—*5	—*5
U2007:46	×	×	—		—	—*5	—	—	×	—	—
U2007:62	—	—	—		—	—	—	—	×	—	—
U2101:00 U2300:52 U2300:54 U2300:55 U2300:56 U2300:64	—	×	—		—	—	—	—	—	—	—
U3000:49	—	—*5	—		—	—	—	—	—	—	—
U3003:08	×	×	×		×	×	×	×	×	×	×
U3003:16	—	×*6 —*7*8	—		—	—	—	—	—	—	—
U3003:17	—	—	—		—	—	—	—	—	—	—

*1 : ATX
*2 : With Tire Pressure Monitoring System (TPMS)
*3 : With Smart City Brake Support (SCBS)
*4 : Control disabled when two wheels or more have a malfunction
*5 : Enabled depending on malfunction content
*6 : When power supply voltage is 7.9—9.6 V for 0.7 s or more
*7 : When power supply voltage is 6.0—7.9 V for 0.8 s or more
*8 : When power supply voltage is 6 V or less for 0.05 s or more