SYMPTOM TROUBLESHOOTING [ANTILOCK BRAKE SYSTEM (ABS)]

id040308804200

- Verify the symptoms, and perform troubleshooting according to the appropriate number.

No.	Symptom
1	Any of the following lights are not illuminated when the ignition is switched ON: • ABS warning light • Brake system warning light
2	ABS warning light remains illuminated
3	Brake system warning light remains illuminated
4	A malfunction in the system even though the ABS warning light and brake system warning light are not illuminated
5	ABS operates frequently

X: Applied

Troubleshooting item	1 **Any of the following lights are not illuminated when the ignition is switched ON:** • ABS warning light • Brake system warning light	2 **ABS warning light remains illuminated**	3 **Brake system warning light remains illuminated**	4 **A malfunction in the system even though the ABS warning light and brake system warning light are not illuminated**	5 **ABS operates frequently**
ABS HU/CM does not operate	X	X	X		
Communication error between ABS HU/CM and instrument cluster	X	X	X		
ABS HU/CM internal malfunction	X	X	X		
Instrument cluster malfunction	X	X	X		
Brake fluid amount is low			X		
ABS HU/CM detected malfunction (input and output device malfunction)		X	X		X
ABS HU/CM detects low voltage in power supply		X	X		
ABS HU/CM ground malfunction	X	X	X		
No connection at ABS HU/CM connector		X	X		
Parking brake does not release			X		
Parking brake switch or brake fluid level sensor stuck on			X		
Short to ground in wiring harness between parking brake switch and instrument cluster			X		
Short to ground in wiring harness between brake fluid level sensor and Body Control Module (BCM)			X		
Mechanical malfunction in system				X	
Incorrect ABS wheel-speed signal is inputted to ABS HU/CM		X			X
Difference in size, air pressure or wear conditions between front and rear tires					X
ABS HU/CM initial setting has not been performed after replacing ABS HU/CM		X			
Input signal malfunction from instrument cluster (parking brake signal)			X		
Communication error between ABS HU/CM and PCM		X			