NO.5 ABS OR TCS*1 OPERATES FREQUENTLY/TCS DOES NOT WORK CORRECTLY *1: DSC SYSTEM FUNCTION CONTAINS TRACTION CONTROL FUNCTION, TCS/DSC INDICATOR LIGHT TURNS ON AND OFF WHILE TCS OPERATES [DYNAMIC STABILITY CONTROL (DSC)]

id0403b2897500

5	**ABS or TCS*1 operates frequently** **TCS does not work correctly** ***1: DSC system function contains traction control function, TCS/DSC indicator light turns on and off while TCS operates**
POSSIBLE CAUSE	• Difference in size or air pressure between front and rear tires. • Incorrect ABS wheel-speed signal is input to DSC HU/CM. • Malfunction in engine control system. (TCS malfunction)

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**CONFIRM DSC HU/CM AND PCM DTC** • Retrieve the DSC HU/CM DTC using the M-MDS. (See DTC INSPECTION [DSC HU/CM].) • Retrieve the PCM DTC using the M-MDS, if the traction control function has a problem. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC INSPECTION [DSC HU/CM].) (See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See DTC TABLE [SKYACTIV-D 1.5].)
		No	Go to the next step.
2	**INSPECT TIRE SIZE AND AIR PRESSURE** • Inspect tire size and air pressure. • Is the tire size and air pressure as specified?	Yes	Go to the next step.
		No	Replace with specified tires and adjust tire air pressure.
3	**INSPECT ABS WHEEL-SPEED SENSOR** • Inspect for each ABS wheel-speed sensor. (See FRONT ABS WHEEL-SPEED SENSOR INSPECTION.) (See REAR ABS WHEEL-SPEED SENSOR INSPECTION.) • Is the ABS wheel-speed sensor normal?	Yes	Found malfunctioning part according to the “INTERMITTENT CONCERN TROUBLESHOOTING”. (See PRECAUTION [DYNAMIC STABILITY CONTROL (DSC)].)
		No	ABS wheel-speed sensor installation inspection: • Inspect the ABS wheel-speed sensor for looseness and confirm it is securely installed. ABS sensor rotor installation inspection: • Inspect the ABS sensor rotor for poor installation. Repair or replace any malfunctioning parts according to the inspection result.