
ABS

id041300183700

Outline


- Electronic Brakeforce Distribution (EBD) has been adopted for improved safety.
- The ABS HU/CM, integrating both the hydraulic unit (HU) and control module (CM), has been adopted, resulting in a size and weight reduction of the system.
- An enhanced malfunction diagnosis system made possible by the use of Mazda Modular Diagnostic System (M-MDS) has improved serviceability.
- Serviceability improved by the automatic configuration function.

Structural View
L.H.D.



am2zzn00002684


R.H.D.



am2zzn00002685

cardiagn.com


Vehicle rear side



am2zzn00002686

cardiagn.com


System Wiring Diagram



cardiagn.com

am2zzn00003587

Warning light and indicator light



am2zzn00002566

No.	Warning/ Indicator	Name	Function
1	(ABS)	ABS warning light	• When the ABS control is disabled, the warning light illuminates to notify the driver
2	(!)	Brake system warning light	• When the parking brake is applied, the warning light illuminates to notify the driver. • When the ABS control and EBD control are disabled with the parking brake released, the warning light illuminates to notify the driver

cardiag.com