CONTROLLER AREA NETWORK (CAN)

id041500104800

Outline

- The DSC HU/CM sends and receives data to and from other modules via the CAN system. Refer to MULTIPLEX COMMUNICATION SYSTEM for a detailed explanation of the CAN system. (See MULTIPLEX COMMUNICATION SYSTEM.)

Data sent

- Brake status
- Cruise control system-related information
- DSC system-related information
- Engine Status
- i-stop related information
- Smart City Brake Support (SCBS)-related information
- Vehicle speed
- Wheel speed (LF, RF, LR, RR)
- Yaw rate
- Lateral-G
- Longitudinal-G

Data received

- Acceleration signal status
- Accelerator pedal opening angle
- Air bag system warning light on request
- Ambient temperature
- ATX gear position
- Back-up light on request
- Back-up light switch
- Battery charge status
- Brake light status
- Brake switch (No.1 signal)
- Clutch pedal stroke sensor
- Collision detection (front, side, roll over)
- Collision detection (rear)
- Cruise control control status
- Cruise control set speed
- Cruise control switch
- Cruise control switch signal
- Cruise control system-related information
- Driving condition
- DSC OFF switch status
- DSC system-related information
- Engine displacement
- Engine speed
- Engine torque
- Fuel cut request
- Hands-free telephone system-related information
- Ignition key status
- Ignition off timer
- i-stop related information
- Manual shift control
- Parking brake status
- Rolling counter
- Shift range position
- Smart City Brake Support (SCBS)-related information
- Steering angle (relative steering angle) signal
- Target gear position
- Tire size
- TPMS OFF switch status
- Traveled distance
- Vehicle speed
- Yaw rate
- Lateral-G
- Longitudinal-G