
## DSC LOCATION INDEX

id041500802100


### Vehicle Front Side (L.H.D.)




am2zzw00007324

| | |
|---|---|
| 1 | DSC HU/CM<br>(See DSC HU/CM REMOVAL/INSTALLATION [L.H.D.].)<br>(See DSC RELATED PARTS SENSOR INITIALIZATION PROCEDURE.)<br>(See DSC HU/CM INSPECTION.) |
| 2 | Brake fluid pressure sensor (built-into DSC HU/CM)<br>(See BRAKE FLUID PRESSURE SENSOR INSPECTION.)<br>(See DSC RELATED PARTS SENSOR INITIALIZATION PROCEDURE.) |
| 3 | DSC OFF switch<br>(See DSC OFF SWITCH REMOVAL/INSTALLATION.)<br>(See DSC OFF SWITCH INSPECTION.) |
| 4 | Smart City Brake Support (SCBS) OFF switch (vehicles with Smart City Brake Support (SCBS) OFF switch)<br>(See SMART CITY BRAKE SUPPORT (SCBS) OFF SWITCH REMOVAL/INSTALLATION.)<br>(See SMART CITY BRAKE SUPPORT (SCBS) OFF SWITCH INSPECTION.) |
| 5 | Front ABS wheel-speed sensor<br>(See FRONT ABS WHEEL-SPEED SENSOR REMOVAL/INSTALLATION.)<br>(See FRONT ABS WHEEL-SPEED SENSOR INSPECTION.) |
| 6 | Laser sensor (vehicles with Smart City Brake Support (SCBS))<br>(See LASER SENSOR INSPECTION.)<br>(See LASER SENSOR REMOVAL/INSTALLATION.) |

**Vehicle Front Side (R.H.D.)**





am2zzw00007325

| | |
|---|---|
| 1 | DSC HU/CM<br>(See DSC HU/CM REMOVAL/INSTALLATION [R.H.D.].)<br>(See DSC RELATED PARTS SENSOR INITIALIZATION PROCEDURE.)<br>(See DSC HU/CM INSPECTION.) |
| 2 | Brake fluid pressure sensor (built-into DSC HU/CM)<br>(See BRAKE FLUID PRESSURE SENSOR INSPECTION.)<br>(See DSC RELATED PARTS SENSOR INITIALIZATION PROCEDURE.) |
| 3 | DSC OFF switch<br>(See DSC OFF SWITCH REMOVAL/INSTALLATION.)<br>(See DSC OFF SWITCH INSPECTION.) |
| 4 | Smart City Brake Support (SCBS) OFF switch (vehicles with Smart City Brake Support (SCBS) OFF switch)<br>(See SMART CITY BRAKE SUPPORT (SCBS) OFF SWITCH REMOVAL/INSTALLATION.)<br>(See SMART CITY BRAKE SUPPORT (SCBS) OFF SWITCH INSPECTION.) |

| | |
|---|---|
| 5 | Front ABS wheel-speed sensor<br>(See FRONT ABS WHEEL-SPEED SENSOR REMOVAL/INSTALLATION.)<br>(See FRONT ABS WHEEL-SPEED SENSOR INSPECTION.) |
| 6 | Laser sensor (vehicles with Smart City Brake Support (SCBS))<br>(See LASER SENSOR INSPECTION.)<br>(See LASER SENSOR REMOVAL/INSTALLATION.) |

## Vehicle Rear Side




am2zzw00007326

| | |
|---|---|
| 1 | Rear ABS wheel-speed sensor<br>(See REAR ABS WHEEL-SPEED SENSOR REMOVAL/INSTALLATION [REAR BRAKE (DRUM)].)<br>(See REAR ABS WHEEL-SPEED SENSOR REMOVAL/INSTALLATION [REAR BRAKE (DISC)].)<br>(See REAR ABS WHEEL-SPEED SENSOR INSPECTION.) |