DTC P0715:00 [TCM (CW6A-EL)]

id0502p4817600

DTC P0715:00	**Turbine/input shaft speed sensor/sensor output range malfunction**
DETECTION CONDITION	• Under the following conditions, the difference between engine speed signal and turbine/input shaft speed signal is **400 rpm or more** for **1 s**: — Engine is running. — Turbine/input shaft speed sensor is **9,000 rpm or less**. — The gear shift position is in the neutral condition.
FAIL-SAFE FUNCTION	• Set to TCC control. • Inhibits learning control. • Inhibits manual mode. • Inhibits i-stop control. • Inhibits AAS. • Inhibits 5GR and 6GR. • Inhibits shift down when the accelerator pedal is depressed.
POSSIBLE CAUSE	• Turbine/input shaft speed sensor malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**RECORD VEHICLE STATUS WHEN DTC WAS DETECTED TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture of the PC function. • Record the freeze frame data/snap shot data.	—	Go to the next step.
2	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, replace the control valve body. (See CONTROL VALVE BODY REMOVAL/INSTALLATION [CW6A-EL].) Go to the next step.
		No	Replace the control valve body, then go to the next step. (See CONTROL VALVE BODY REMOVAL/INSTALLATION [CW6A-EL].)
3	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Clear the DTC using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (CW6A-EL)].) • Perform the following procedure to ensure that the DTC has been resolved: 1. Drive the vehicle for **1 s or more** under the following condition: • Vehicle speed: **30 km/h {19 mph} or more** • Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (CW6A-EL)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (CW6A-EL)].)
		No	DTC troubleshooting completed.