DTC P0218:00 [TCM (EW6A-EL)]

id0502p7903700

DTC P0218:00	**Automatic transaxle protection control**
DETECTION CONDITION	• Under the following conditions, the ATF temperature is **135 °C {275 °F} or more** for **10 s**: — Engine is running. — TFT sensor related DTC is not recorded.
FAIL-SAFE FUNCTION	• Inhibits learning control. • Inhibits manual mode. • Inhibits neutral idle control. • Inhibits i-stop control. • Inhibits AAS.
POSSIBLE CAUSE	• Oil cooler malfunction • ATF is more than specified value
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**RECORD VEHICLE STATUS WHEN DTC WAS DETECTED TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture of the PC function. • Record the freeze frame data/snap shot data.	—	Go to the next step.
2	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	**INSPECT ATF LEVEL** • Inspect the ATF level. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [EW6A-EL].) • Is there any malfunction?	Yes	Adjust the ATF level to the specification, then go to Step 5. (See AUTOMATIC TRANSAXLE FLUID (ATF) ADJUSTMENT [EW6A-EL].)
		No	Go to the next step.
4	**INSPECT OIL COOLER** • Visually inspect the oil cooler. • Is there any malfunction?	Yes	Replace the oil cooler, then go to the next step. (See OIL COOLER REMOVAL/INSTALLATION [EW6A-EL].)
		No	Go to the next step.
5	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Clear the DTC using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].) • Perform the following procedure to ensure that the DTC has been resolved: 1. Start the engine and wait for **10 s or more**. • Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (EW6A-EL)].)
		No	DTC troubleshooting completed.