## DTC U0442:00 [TCM (EW6A-EL)]

id0502p7905300

| | |
|---|---|
| **DTC U0442:00** | **Invalid data received from PCM (local CAN between TCM and PCM)** |
| **DETECTION CONDITION** | • Under the following condition, the TCM detects the invalid PCM signal for **0.5 s**:<br>— Battery voltage is **10 V or more**. |
| **FAIL-SAFE FUNCTION** | • Set to TCC control.<br>• Inhibits learning control.<br>• Inhibits manual mode.<br>• Inhibits neutral idle control.<br>• Inhibits 5GR and 6GR.<br>• Inhibits shift down when the accelerator pedal is depressed. |
| **POSSIBLE CAUSE** | • PCM DTC is stored. |
| **SYSTEM WIRING DIAGRAM** | Not applicable |

### Diagnostic procedure

| STEP | INSPECTION | | ACTION |
|---|---|---|---|
| 1 | **VERIFY RELATED SERVICE INFORMATION AVAILABILITY**<br>• Verify related Service Information availability.<br>• Is any related Service Information available? | Yes | Perform repair or diagnosis according to the available Service Information.<br>• If the vehicle is not repaired, go to the next step. |
| | | No | Go to the next step. |
| 2 | **VERIFY PCM DTC**<br>• Perform the PCM DTC inspection using the M-MDS.<br>(See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].)<br>• Are any DTCs present? | Yes | Go to the applicable DTC inspection.<br>(See DTC TABLE [SKYACTIV-D 1.5].) |
| | | No | Go to the next step. |
| 3 | **VERIFY DTC TROUBLESHOOTING COMPLETED**<br>• Clear the DTC using the M-MDS.<br>(See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].)<br>• Perform the following procedure to ensure that the DTC has been resolved:<br>1. Start the engine and warm it up completely.<br>2. Drive the vehicle for a while under the following conditions:<br>• Selector lever position: D position<br>• Perform the DTC inspection using the M-MDS.<br>(See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].)<br>• Are any DTCs present? | Yes | Go to the applicable DTC inspection.<br>(See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (EW6A-EL)].) |
| | | No | DTC troubleshooting completed. |