MANUAL SHIFT MODE INDICATION DOES NOT ILLUMINATE IN M POSITION/MANUAL SHIFT MODE INDICATION ILLUMINATES IN D POSITION [EW6A-EL]

id050322113600

TROUBLESHOOTING ITEM	**Manual shift mode indication does not illuminate in M position/Manual shift mode indication illuminates in D position**
DESCRIPTION	• Manual shift mode indication in instrument cluster does not illuminate in M position or manual shift mode indication in instrument cluster in P, R, N and D positions with the ignition switched ON (engine off or on).
POSSIBLE CAUSE	1. Instrument cluster malfunction

Diagnostic procedure

STEP	INSPECTION		ACTION
1	**INSPECT INSTRUMENT CLUSTER FOR MALFUNCTION** • Inspect the instrument cluster. (See INSTRUMENT CLUSTER INSPECTION.) • Is there any malfunction?	Yes	Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
		No	Symptom troubleshooting is completed.