CLUTCH [F65M-R]


id0510q1283600

Purpose, Function

- The clutch unit transmits or cuts engine force to the manual transaxle according to the clutch pedal operation.

Construction, Operation

- The construction/operation of the clutch unit is the same as the original manual transaxle (ex: C66M-R).



am2zzn00002406