## CLUTCH STROKE SENSOR REMOVAL/INSTALLATION [F66M-R]

id0510q2156900

**Note**
- The clutch stroke sensor is equipped only on vehicles with i-stop.
- The clutch stroke sensor is built into the clutch master cylinder.

1. Replace the clutch master cylinder. (See CLUTCH MASTER CYLINDER REMOVAL/INSTALLATION [F66M-R].)