CLUTCH FLUID LEAKAGE INSPECTION [F66M-R]


id0510q2158400

Caution

- **Do not allow clutch fluid to get on a painted surface. Clutch fluid contains properties which can dissolve the paint. If clutch fluid gets on a painted surface, rinse with water immediately, then wipe the area dry.**

1. Verify reserve tank cap is on tight.
2. Pump the clutch pedal a few times.
3. Inspect for the clutch fluid leakage at the points indicated in the figure.

L.H.D.




am2zzw00010013

R.H.D.

Note

- If there is clutch fluid leakage from the piston in the clutch release cylinder, there is clutch fluid in the boot of clutch release cylinder.

- If there is clutch fluid leakage, repair or replace the malfunctioning location.



adejjw00013432