CLUTCH [F66M-R]

id0510q2283600


SKYACTIV-G 1.5

Purpose, function

- The clutch unit transmits or cuts engine force to the manual transaxle according to the clutch pedal operation.

Construction, operation

- The construction/operation of the clutch unit is the same as the original manual transaxle (ex: C66M-R).




am2zzn00002408

SKYACTIV-D 1.5
Purpose, function

- The clutch unit transmits or cuts engine force to the manual transaxle according to the clutch pedal operation.

Construction, operation

- The construction/operation of the clutch unit is the same as the original manual transaxle (ex: D66M-R).
- The wear assurance function of the clutch cover maintains the set load of the clutch cover unchanged even as the clutch disc becomes worn, thereby extending disc life.



am2zzn00002409