
MANUAL TRANSAXLE SHIFT MECHANISM LOCATION INDEX [F66M-R]

id0516n2160600



adejjw00012174

1	Shift lever (See MANUAL TRANSAXLE SHIFT MECHANISM REMOVAL/INSTALLATION [F66M-R].)
2	Control cable (See MANUAL TRANSAXLE SHIFT MECHANISM REMOVAL/INSTALLATION [F66M-R].)