DOWN SWITCH REMOVAL/INSTALLATION [CW6A-EL]

id0517I1112300

Note
- The down switch is built into the selector lever component.

1. If the down switch is replaced, replace the selector lever component. (See AUTOMATIC TRANSAXLE SHIFT MECHANISM REMOVAL/INSTALLATION.)