OUTPUT GEAR [CW6A-EL]


id0517I1352100

Purpose/Function

- The output gear transmits the drive force transmitted from the primary gear and secondary gear to the differential.

Construction

- The output gear is engaged with the secondary gear and rotates as a single unit.



am2zzn00002343