## ELECTRIC AT OIL PUMP [CW6A-EL]


id0517I1355200

### Purpose, Function

- The electric AT oil pump generates hydraulic pressure in the oil line of the automatic transaxle when the i-stop (engine-stop control) permit conditions are met and the engine is stopped.
- By ensuring oil pressure while i-stop is operating, smooth startability after the engine is restarted has been realized.

### Construction

- The electric oil pump has adopted an axial piston type.
- The electric AT oil pump is installed to the transaxle end cover.




am2zzn00002337

### Operation

- The electric oil pump generates hydraulic pressure by the operation of the electric motor based on the operation signal from the TCM.