M POSITION SWITCH INSPECTION [CW6A-EL]

(4) Remove the selector lever knob.

3. Remove the following parts:
   (1) Center console tray (See CENTER CONSOLE TRAY REMOVAL/INSTALLATION.)
   (2) Shift bezel (See SHIFT BEZEL REMOVAL/ INSTALLATION.)
   (3) Upper panel (See UPPER PANEL REMOVAL/ INSTALLATION.)
   (4) Shift panel (See SHIFT PANEL REMOVAL/ INSTALLATION.)
   (5) Console side panel (See CONSOLE SIDE PANEL REMOVAL/INSTALLATION.)
   (6) Front console box (See FRONT CONSOLE BOX REMOVAL/INSTALLATION.)
   (7) CD player (with CD player) (See CD PLAYER REMOVAL.) (See CD