(4) Remove the selector lever knob.

3. Remove the following parts: