M POSITION SWITCH REMOVAL/INSTALLATION [EW6A-EL]

id0517I2100000

Note
- The M position switch is built into the selector lever component.

1. If the M position switch is replaced, replace the selector lever component. (See AUTOMATIC TRANSAXLE SHIFT MECHANISM REMOVAL/INSTALLATION.)