UP SWITCH REMOVAL/INSTALLATION [EW6A-EL]

id0517l2112200

Note
- The up switch is built into the selector lever component.

1. If the up switch is replaced, replace the selector lever component. (See AUTOMATIC TRANSAXLE SHIFT MECHANISM REMOVAL/INSTALLATION.)