OIL COOLER [EW6A-EL]


id0517I2358100

Purpose/Function

- The oil cooler constantly maintains maximum ATF performance in the transaxle by maintaining an optimum ATF temperature which has the effect of achieving reduced fuel consumption.

Construction/Operation

- The oil cooler performs the following operations according to the ATF temperature condition:
  - — Heating function: Warms the ATF using the radiator coolant to promote an earlier increase in the ATF temperature when its temperature is low. As a result of the earlier temperature increase, the ATF viscosity decreases which reduces drag in the transaxle.
  - — Cooling function: Cools the ATF using the radiator coolant to maintain optimum conditions and prevent ATF expansion and deterioration.



am2zzn00002366