STEERING GEAR AND LINKAGE

id067000000200

Purpose of Adoption
- A steering column with a tilt/telescoping mechanism has been adopted to enable precise adjustment for an optimum driving posture.

Service Point
- Not applicable

Common Inquiry
- After releasing the tilt/telescoping lever and adjusting the steering wheel position, the tilt cam may not engage with the teeth on the opposite side and the lever cannot be locked.
- If they do not engage, move the steering wheel slightly and return the lever slowly to lock the lever.

Other
- The steering wheel can be moved in the up/down and forward/backward direction by pressing the adjusting lever towards the front of the vehicle and releasing the lock of the tilt/telescoping system.
- The tilt/telescoping mechanism allows adjustment for **45 mm {1.8 in}** in the vertical direction and **50 mm {2.0 in}** in the longitudinal direction.
- Generally, the telescoping operation may feel heavy if it is operated by one hand or holding the lower part (6-o'clock position) or upper part (12-o'clock position) of the steering wheel. It can be operated smoothly by holding the steering wheel in the 3-o'clock and 9-o'clock positions.