
AIR FILTER

id071100001600

Purpose, Function

- The air filter removes pollen and dust in the air entering the blower unit from the FRESH or RECIRCULATE modes and cleans the airflow sent to the cabin.



am2zzn00002104

Construction

- The air filter is set in the blower unit.
- It is necessary to periodically replace the air filter because it cannot be reused by cleaning.

Fail-safe

- Not applicable