## A/C COMPRESSOR


id071100001800

### Purpose
- The A/C compressor circulates the gaseous refrigerant in the refrigeration cycle.


### Function
- The A/C compressor intakes gaseous refrigerant by the rotor rotation and discharges the compressed gaseous refrigerant.

### Construction
- The A/C compressor has adopted a rotary vane type compressor.

**SKYACTIV-G-1.3, SKYACTIV-G-1.5**





**SKYACTIV-D 1.5**




am2zzn00002105

- The A/C compressor consists of the following parts.




am2zzn00002106

### Operation
- When the rotor rotates, the oblong-shaped rotor vanes expand along the inner circumference of the cylinder sealing the air in the cylinder and rotor space to produce a compression effect whereby intake of gaseous refrigerant, compression and discharge is performed.
- For the magnetic clutch operation, refer to the REFRIGERANT SYSTEM. (See REFRIGERANT SYSTEM.)

### Fail-safe
- Not applicable