
MAGNET CLUTCH

id071100001900


Purpose, Function
- The magnetic clutch engages or disengages the magnetic clutch.

Construction
- The magnetic clutch is installed to the A/C compressor.
- The magnetic clutch consists of the following parts.

SKYACTIV-G-1.3, SKYACTIV-G-1.5



SKYACTIV-D 1.5



adejjn00002815

Operation
- For the magnetic clutch operation, refer to the REFRIGERANT SYSTEM. (See REFRIGERANT SYSTEM.)

Fail-safe
- Not applicable