CONDENSER

id071100002200


Purpose, Function

- The condenser cools the high temperature, high pressure gaseous refrigerant circulating internally using airflow from the exterior and changes it to low temperature, low pressure liquid refrigerant.

Construction


SKYACTIV-G 1.3, SKYACTIV-G 1.5

- The condenser is positioned at the front of the radiator.
- The condenser consists of the tube which passes refrigerant, and the heat radiation fins.



am2zzn00002112


- A multi-flow type (sub-cooling type) condenser has been adopted.
- The multi-flow type (sub-cooling type) is a condenser with an integrated receiver/drier.
- The multi-flow type (sub-cooling type) separates the refrigerant, cooled once by the condenser, into vapor and liquid using the receiver/drier, and by returning it to the sub-cooling part of the condenser again to cool it.
- As a result, liquification of the refrigerant is promoted and cooling performance is improved.



am2zzn00002113


SKYACTIV-D 1.5

- The condenser is positioned at the front of the radiator.
- The condenser consists of the tube which passes refrigerant, and the heat radiation fin.



am2zzn00002114

- A multi-flow type condenser has been adopted.



adejjn00002821

Operation

- For the condenser operation, refer to the REFRIGERANT SYSTEM. (See REFRIGERANT SYSTEM.)

Fail-safe

- Not applicable