
RESISTOR

id071100011600

Purpose
- The resistor controls the blower motor rotation speed.

Function
- The resistor controls the supply voltage to the blower motor according to the fan switch conditions, and adjusts the blower motor rotation speed (airflow volume).

Construction
- The resistor is positioned in the A/C unit.
- A thin, card type resistor has been adopted.



am2zzn00002125

Operation
- For the resistor operation, refer to the BLOWER SYSTEM. (See BLOWER SYSTEM.)

Fail-safe
- Not applicable