
FRONT HEAT DUCT REMOVAL/INSTALLATION

id071100307100


Installation position



am2zzw00009862

Driver-side

1. Remove the driver-side side wall. (See SIDE WALL REMOVAL/INSTALLATION.)
2. Detach the tab.




am2zzw00009574

3. Remove the driver-side front heat duct.
4. Install in the reverse order of removal.

Passenger-side

1. Remove the passenger-side side wall. (See SIDE WALL REMOVAL/INSTALLATION.)
2. Remove the dashboard under cover. (See DASHBOARD UNDER COVER REMOVAL/INSTALLATION.)
3. Detach the tab.



am2zzw00009575

4. Remove the passenger-side front heat duct.
5. Install in the reverse order of removal.