AIRFLOW MODE ACTUATOR [FULL-AUTO AIR CONDITIONER]


id0740a1004900

Purpose
- The airflow mode actuator opens/closes the airflow mode door in the A/C unit to switch the air vent.

Function
Door open/close function
- The door open/close function opens/closes the VENT, BI-LEVEL, HEAT, DEF/HEAT or DEFROSTER positions.

Door position detection function
- The door position detection function fluctuates the potentiometer voltage value which is linked to the airflow mode actuator motor drive.

Construction
- A potentiometer-type airflow mode actuator has been adopted.
- The airflow mode actuator is located on the front passenger side of the A/C unit.
- The operation range of the airflow mode actuator is as indicated in the diagram.



am2zzn00002155

Operation
- For the airflow mode actuator operation, refer to the FULL-AUTO AIR CONDITIONING SYSTEM [FULL-AUTO AIR CONDITIONER]. (See FULL-AUTO AIR CONDITIONER SYSTEM [FULL-AUTO AIR CONDITIONER].)

Fail-safe
- Not applicable