DTC B0003:53 [STANDARD DEPLOYMENT CONTROL SYSTEM]

id0802b1821000

System malfunction location	• Operation (deployment) inhibited
Detection condition	**Warning** **• Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure.** • The SAS control module configuration has not been set • The SAS control module configuration has been set, but air bag system is not normal
Fail-safe function	Not applicable
Possible cause	• SAS control module configuration setting not implemented • Air bag system malfunction • SAS control module malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY THAT NO OTHER DTCs ARE PRESENT** • Are any other DTCs output?	Yes	Repair the malfunction part according to the applicable DTC troubleshooting. (See DTC TABLE [STANDARD DEPLOYMENT CONTROL SYSTEM].)
		No	Go to the next step.
2	**PERFORM SAS CONTROL MODULE CONFIGURATION (AS-BUILT DATA USE)** • Perform the SAS control module configuration using the M-MDS. (See SAS CONTROL MODULE CONFIGURATION (USING AS-BUILT DATA) [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Are the same DTCs present?	Yes	Go to the next step.
		No	DTC troubleshooting completed.
3	**PERFORM SAS CONTROL MODULE DTC INSPECTION** • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Are the same DTCs present?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/ INSTALLATION [STANDARD DEPLOYMENT CONTROL SYSTEM].)
		No	Go to the next step.

Step	Inspection		Action
4	**VERIFY THAT NO OTHER DTCs ARE PRESENT** • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [STANDARD DEPLOYMENT CONTROL SYSTEM].) • Are any other DTCs output?	Yes	Repair the malfunction part according to the applicable DTC troubleshooting. (See DTC TABLE [STANDARD DEPLOYMENT CONTROL SYSTEM].)
		No	DTC troubleshooting completed.

cardiagn.com