DTC U3000:49 [STANDARD DEPLOYMENT CONTROL SYSTEM]

id0802b1824800

System malfunction location	**SAS control module internal malfunction**
Detection condition	**Warning** **• Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure.** • SAS control module internal circuit has a malfunction
Fail-safe function	Not applicable
Possible cause	• SAS control module malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

ACTION
Replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION [STANDARD DEPLOYMENT CONTROL SYSTEM].)