CRASH ZONE SENSOR [STANDARD DEPLOYMENT CONTROL SYSTEM]

id0810b2511300

Purpose

- The crash zone sensor detects an impact during a frontal or frontal offset collision of the vehicle.

Function

- The crash zone sensor converts the de