
SEAT BELT LOCATION INDEX

id081100804200



am2zzw00009807

1	Rear seat belt (See REAR SEAT BELT REMOVAL/ INSTALLATION.) (See SEAT BELT INSPECTION.)
2	Rear center seat belt (See REAR CENTER SEAT BELT REMOVAL/ INSTALLATION.) (See SEAT BELT INSPECTION.)
3	Adjuster anchor (See ADJUSTER ANCHOR REMOVAL/ INSTALLATION.)
4	Front seat belt (See FRONT SEAT BELT REMOVAL/ INSTALLATION.) (See SEAT BELT INSPECTION.)

5	Front buckle (See FRONT BUCKLE REMOVAL/ INSTALLATION.) (See BUCKLE SWITCH INSPECTION.)
6	Rear buckle (See REAR BUCKLE REMOVAL/INSTALLATION.) (See BUCKLE SWITCH INSPECTION.)