SECURITY INDICATOR LIGHT: 09, DTC: U3000:96/P1260:00 [IMMOBILIZER SYSTEM]

id0902e4028200

Description	Start stop unit malfunction
Detection condition	• Start stop unit malfunction detected.
Fail-safe	Not applicable
Possible cause	• Start stop unit malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IF MALFUNCTIONING LOCATION IS START STOP UNIT DEPENDING ON REPEATABILITY** • Clear the DTC for the immobilizer system using the M-MDS. (See CLEARING DTC [IMMOBILIZER SYSTEM].) • Retrieve the immobilizer system DTCs using the M-MDS. (See DTC INSPECTION [IMMOBILIZER SYSTEM].) • Is the security indicator light: 09, DTC U3000:96/P1260:00 displayed?	Yes	Replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No	Go to the next step.
2	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [IMMOBILIZER SYSTEM].)
		No	DTC troubleshooting completed.