Diagnostic Procedure

(Step DTC INSPECTION [FORWARD SENSING CAMERA (FSC)]) •Are any DTCl displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FORWARD SENSING CAMERA (FSC)])
	No	Go to the next step.