DTC INSPECTION [BCM]

id0902f5067300

CMDTC Self Test

1. Connect the M-MDS to the DLC-2.
2. Verify the following vehicle conditions: