DTC: 30:Er01 [AUDIO]

id0902f6036700

Description	CD player mechanism malfunction
Detection condition	CD player mechanism malfunction detected.
Fail-safe	Not applicable
Possible cause	• Disc malfunction or malfunction due to customer use method — CD insertion direction mistaken — CD scratching or soiling — Incompatible CD used • CD player malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IF MALFUNCTIONING LOCATION IS DISC** • After obtaining the customer's consent, insert a disc that was not used when the malfunction occurred into the CD player. • Does the disc play normally?	Yes	System is normal. (Explain to the customer that there is a malfunction in the disc or malfunction due to the customer use method.)
		No	Go to the next step.
2	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the CD player. (See CLEARING DTC [AUDIO].) • Perform a CD inspection using the diagnostic assist function. (See DIAGNOSTIC ASSIST FUNCTION [AUDIO].) • Perform the DTC inspection for CD player. (See DTC INSPECTION [AUDIO].) • Is the same DTC displayed?	Yes	Replace the CD player, then go to the next step. (See CD PLAYER REMOVAL.) (See CD PLAYER INSTALLATION.)
		No	Go to the next step.
3	**VERIFY OTHER DTCs** • Are any other DTCs displayed?	Yes	Repair the malfunctioning location according to the applicable DTC troubleshooting. (See DTC TABLE [AUDIO].)
		No	DTC troubleshooting completed.