DTC: 30:Er30 [AUDIO]

id0902f6036900

Description	CD player temperature abnormality
Detection condition	Abnormal temperature in CD player is detected.
Fail-safe	Not applicable
Possible cause	**Caution** **• If the CD player is used for long periods in a hot environment, the temperature of the CD player will increase and a DTC may be output. The CD player should not be used continuously for long periods with the cabin under high temperature conditions from being left under direct sunlight.** • Temporary abnormality due to continuous use • CD player malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IF CD PLAYER TEMPERATURE WAS TEMPORARILY HIGH** • Leave the vehicle in a cool location for **30 min or more**. • Clear the DTC for the CD player. (See CLEARING DTC [AUDIO].) • Switch the ignition ON (engine off or on). • Perform the DTC inspection for CD player. (See DTC INSPECTION [AUDIO].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 3.
2	**VERIFY THAT REPAIRS HAVE BEEN COMPLETED** • Clear the DTC for the CD player. (See CLEARING DTC [AUDIO].) • Perform a CD inspection using the diagnostic assist function. (See DIAGNOSTIC ASSIST FUNCTION [AUDIO].) • Perform the DTC inspection for CD player. (See DTC INSPECTION [AUDIO].) • Is the same DTC displayed?	Yes	Replace the CD player, then go to the next step. (See CD PLAYER REMOVAL.) (See CD PLAYER INSTALLATION.)
		No	Go to the next step.
3	**VERIFY OTHER DTCs** • Are any other DTCs displayed?	Yes	Repair the malfunctioning location according to the applicable DTC troubleshooting. (See DTC TABLE [AUDIO].)
		No	DTC troubleshooting completed.