DTC TABLE [AUDIO]

id0902f6855700

Note
- If an audio unit DTC is indicated, refer to For Audio Unit below.
- If a Bluetooth® unit DTC is indicated, refer to For Bluetooth® Unit below. (With Bluetooth® unit)
- If a CD player DTC is indicated, refer to For CD Player below. (With CD player)

For Audio Unit

×: Applicable
—: Not applicable

DTC No.	Warning/ indicator light	Description	Fail-safe	Drive cycle	Memory function	Page
16:Er11*1	—	CAN communication time-out	—	—	×	(See DTC: 16:Er11, 16:Er12, 26:Er81 [AUDIO].)
16:Er12*1	—	Unit communication error	—	—	×	
28:Er09	—	No USB playback function file/ track	—	—	×	(See DTC: 28:Er09 [AUDIO].)
No Err	—	DTCs are not stored.	—	—	—	—

*1 : With CD player or with Bluetooth® unit

For Bluetooth® Unit

—: Not applicable

DTC No.	Warning/ indicator light	Description	Fail-safe	Drive cycle	Memory function	Page
26:Er81	—	Communication error with Bluetooth® unit	—	—	—	(See DTC: 16:Er11, 16:Er12, 26:Er81 [AUDIO].)
26:Er82	—	Microphone circuit malfunction	—	—	—	(See DTC: 26:Er82 [AUDIO].)
26:Er83	—	Microphone circuit malfunction	—	—	—	(See DTC: 26:Er83 [AUDIO].)
26:Er84	—	Microphone circuit malfunction	—	—	—	(See DTC: 26:Er84 [AUDIO].)
26:Er85	—	Steering switch circuit malfunction	—	—	—	(See DTC: 26:Er85 [AUDIO].)
26:Er86	—	Bluetooth® unit internal malfunction	—	—	—	(See DTC: 26:Er86 [AUDIO].)
No Err	—	DTCs are not stored.	—	—	—	—

For CD Player

×: Applicable
—: Not applicable

DTC No.	Warning/ indicator light	Description	Fail-safe	Drive cycle	Memory function	Page
30:Er01	—	CD player mechanism malfunction	—	—	×	(See DTC: 30:Er01 [AUDIO].)
30:Er07	—	CD player data read error	—	—	×	(See DTC: 30:Er07 [AUDIO].)
30:Er30	—	CD player temperature abnormality	—	—	×	(See DTC: 30:Er30 [AUDIO].)
No Err	—	DTCs are not stored.	—	—	—	—