.

• The electrical supply unit (ESU) detects a short to gro

Description

*2 : With front combination light (LED ty

Step

Step	Inspection	Action
16	**VERIFY IF MALFUNCTIONING LOCATION IS REAR COMBINATION LIGHT (LH) DEPENDING ON REPEATABILITY** • Always reconnect all disconnected connectors.	