INSPECT SAS CONTROL MODULE CONNECTOR CONDIION

- Switch the ignition off.
- Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.)
- Disconnect the SAS control module connector.e 15 TS-0Sch thttery TTER33tor.

Step	Inspection

Step