PID/DATA MONITOR TABLE [HEADLIGHT AUTO LEVELING SYSTEM]

id0902i7960700

PID	Unit/ Operation	Data contents	Module control terminal
H/L_BO_L	OK/NG	Displays the headlight LO (LH) open circuit detection status. (Detects during low beam on)	I
H/L_BO_R	OK/NG	Displays the headlight LO (RH) open circuit detection status. (Detects during low beam on)	Z
R_HGT_S	V	Displays voltage at auto leveling sensor	F, J, T
R_HGT_S_INI	V	Displays voltage at headlight auto leveling system initial setting	F, J, T
VPWR_IG	V	Displays auto leveling control module power supply voltage	A, C
VSPD	KPH, MPH	Displays vehicle speed	AB, AD