DTC U3000:01 [START STOP UNIT]

id0902p6024700

Description	Start stop unit internal malfunction
Detection condition	• Start stop unit detects the internal malfunction.
Fail-safe	Not applicable
Possible cause	• Start stop unit internal malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY IF MALFUNCTIONING LOCATION IS START STOP UNIT DEPENDING ON REPEATABILITY** • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed?	Yes	Replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No	Go to the next step.
2	**VERIFY IF OTHER DTCs DISPLAYED** • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No	DTC troubleshooting completed.