SYMPTOM TROUBLESHOOTING CHART [POWER WINDOW SYSTEM]

id0903a0805600

Troubleshooting item
DRIVER-SIDE DOOR GLASS CAN BE OPERATED MANUALLY BUT CANNOT BE OPERATED AUTOMATICALLY (See DRIVER-SIDE DOOR GLASS CAN BE OPERATED MANUALLY BUT CANNOT BE OPERATED AUTOMATICALLY [POWER WINDOW SYSTEM].)
DRIVER-SIDE DOOR GLASS CANNOT BE OPERATED MANUALLY OR AUTOMATICALLY (See DRIVER-SIDE DOOR GLASS CANNOT BE OPERATED MANUALLY OR AUTOMATICALLY [POWER WINDOW SYSTEM].)
DOOR GLASS OTHER THAN DRIVER'S DOOR CANNOT BE OPERATED (CANNOT BE OPERATED USING EACH SUBSWITCH BUT CAN BE OPERATED USING POWER WINDOW MAIN SWITCH) (See DOOR GLASS OTHER THAN DRIVER'S DOOR CANNOT BE OPERATED (CANNOT BE OPERATED USING EACH SUBSWITCH BUT CAN BE OPERATED USING POWER WINDOW MAIN SWITCH) [POWER WINDOW SYSTEM].)
DOOR GLASS OTHER THAN DRIVER'S DOOR CANNOT BE OPERATED (CANNOT BE OPERATED USING POWER WINDOW MAIN SWITCH BUT CAN BE OPERATED USING EACH SUBSWITCH) (See DOOR GLASS OTHER THAN DRIVER'S DOOR CANNOT BE OPERATED (CANNOT BE OPERATED USING POWER WINDOW MAIN SWITCH BUT CAN BE OPERATED USING EACH SUBSWITCH) [POWER WINDOW SYSTEM].)
DOOR GLASS OTHER THAN DRIVER'S DOOR CANNOT BE OPERATED (CANNOT BE OPERATED USING POWER WINDOW MAIN SWITCH OR EACH SUBSWITCH) (See DOOR GLASS OTHER THAN DRIVER'S DOOR CANNOT BE OPERATED (CANNOT BE OPERATED USING POWER WINDOW MAIN SWITCH OR EACH SUBSWITCH) [POWER WINDOW SYSTEM].)
DRIVER-SIDE DOOR GLASS REVERSE OPENS DURING AUTO-CLOSE (MANUAL-CLOSE) OPERATION (MIS REVERSE OPEN) (See DRIVER-SIDE DOOR GLASS REVERSE OPENS DURING AUTO-CLOSE (MANUAL-CLOSE) OPERATION (MIS REVERSE OPEN) [POWER WINDOW SYSTEM].)
ABNORMAL SOUND DURING DOOR GLASS OPENING/CLOSING (See ABNORMAL SOUND DURING DOOR GLASS OPENING/CLOSING [POWER WINDOW SYSTEM].)