SYMPTOM TROUBLESHOOTING [INTELLIGENT DRIVE MASTER (i-DM)]

id0903k6715100

Malfunction Symptom	Description
Deviation between driving diagnostic score and drive feel (See DEVIATION BETWEEN DRIVING DIAGNOSTIC SCORE AND DRIVE FEEL [INTELLIGENT DRIVE MASTER (i-DM)])	• Frequency of white lamp display is high even though vehicle is driven on level straightaway • Driving diagnostic score according to stage is not displayed • Driving diagnostic score for same driving operation is bad compared with another vehicle of same model
Driving diagnostic display of previous driving not reflected (See DRIVING DIAGNOSTIC DISPLAY OF PREVIOUS DRIVING NOT REFLECTED [INTELLIGENT DRIVE MASTER (i-DM)])	• Displayed stage level may indicate lower level by more than two stages compared with previous driving • Significantly different average score from previous average score is displayed
Intelligent Drive Master lamp not illuminated (See INTELLIGENT DRIVE MASTER LAMP NOT ILLUMINATED [INTELLIGENT DRIVE MASTER (i-DM)])	• Intelligent Drive Master lamp not illuminated • Acceleration/deceleration G, turning angle G rate of change (passenger oscillation speed), and range of change (extent of passenger oscillation) are not reflected in white gauge • White lamp does not work even though acceleration/deceleration G, turning angle G rate of change (passenger oscillation speed), and range of change (extent of passenger oscillation) have changed

Malfunction diagnosis table

X: Applied

Malfunction cause / Malfunction symptom	PCM detects DTC (engine control is in fail-safe)	Accelerator position sensor signal error	Vehicle speed signal error	ABS wheel-speed sensor/sensor rotor malfunction	Engine malfunction (abnormal acceleration, hesitation during acceleration)	Steering angle (estimated absolute steering angle) signal error	EPS control module malfunction	Intelligent drive master screen setting	Communication error between instrument cluster and PCM	Instrument cluster malfunction	Malfunction in instrument cluster backup power supply and ground system (open or short circuit)	Connectivity master unit (CMU) malfunction	Communication error between connectivity master unit (CMU) and PCM
Deviation between driving diagnostic score and drive feel	X	X	X	X	X	X	X			X		X	
Driving diagnostic display of previous driving not reflected								X	X	X	X	X	X
Intelligent Drive Master lamp not illuminated	X	X				X	X	X	X	X		X	

am2zzw00011354