SYMPTOM TROUBLESHOOTING ITEM TABLE [SECURITY AND LOCKS]

id0903k7113500

- Verify the malfunctioning symptom and perform malfunction diagnosis according to the applicable item.

Note

- If a malfunction, such as the door lock does not operate, the advanced keyless entry system does not operate, or the lock/unlock operation cannot be performed using the remote transmitter, does not recur, refer to the [DOOR LOCK SYSTEM OPERATION RECORD] for new vehicle instruction and verify that the content stated by the customer and the content of the door lock system operation record match.

Malfunction symptom	Description
DOOR LOCK DOES NOT OPERATE (See DOOR LOCK DOES NOT OPERATE [SECURITY AND LOCKS].)	• Door cannot be locked/unlocked using key cylinder • Door cannot be locked/unlocked using lock knob • Door cannot be locked/unlocked using request switch • Door cannot be locked/unlocked using remote transmitter
ADVANCED KEYLESS ENTRY SYSTEM DOES NOT OPERATE (See ADVANCED KEYLESS ENTRY SYSTEM DOES NOT OPERATE [SECURITY AND LOCKS].)	• Liftgate/trunk lid does not open even if liftgate/trunk lid opener switch is pressed • Door cannot be locked/unlocked using request switch
LOCK/UNLOCK OPERATION NOT POSSIBLE USING REMOTE TRANSMITTER (See LOCK/UNLOCK OPERATION NOT POSSIBLE USING REMOTE TRANSMITTER [SECURITY AND LOCKS].)	Door cannot be locked/unlocked using remote transmitter
ANSWER-BACK BUZZER DOES NOT SOUND (See ANSWER-BACK BUZZER DOES NOT SOUND [SECURITY AND LOCKS].)	Keyless beeper does not sound
PUSH BUTTON START SYSTEM DOES NOT OPERATE (See PUSH BUTTON START SYSTEM DOES NOT OPERATE [SECURITY AND LOCKS].)	Ignition cannot be switched to ACC or ON (engine off)
STEERING LOCK FUNCTION DOES NOT OPERATE (See STEERING LOCK FUNCTION DOES NOT OPERATE [SECURITY AND LOCKS].)	Steering lock does not operate normally