
FOREWORD [ENTERTAINMENT SYSTEM [WITHOUT CENTER DISPLAY]]

id0903I9059700

Troubleshooting Procedure




am2zzw00011374

*1 : (See DTC Inspection Note.)

Action for non-repeatable malfunction


- If the malfunction does not recur, verify the malfunction cause by performing the following actions:
  — Verify that a DTC has been recorded in the memory. (See DTC INSPECTION [AUDIO].)

— Shake the wiring harness or connector of the electrical component which is suspected to be the cause of the malfunction, and inspect for malfunction or occurrence of any DTCs.



aaxjjw00012432

— Refer to [Determining Open Circuit Location] based on the recorded DTC, shake the wiring harness or connector of the electrical component which is suspected to be the cause of the malfunction, and inspect for any malfunctions or occurrence of any DTCs.



am3zzw00015283

DTC Inspection Note

- The entertainment system [without center display] DTCs can be verified using the on-board diagnostic test mode to activate the on-board diagnostic function by operating the audio unit. (See DTC INSPECTION [AUDIO].)