TROUBLESHOOTING INDEX [PARKING SENSOR]

id0903z4668500

Troubleshooting item	Description
SYSTEM DOES NOT OPERATE (See SYSTEM DOES NOT OPERATE [PARKING SENSOR].)	Buzzer does not sound after ignition is switched ON and the selector lever (ATX)/Shift lever (MTX) is in the R position.
MALFUNCTION DETECTION SOUND ACTIVATED (See MALFUNCTION DETECTION SOUND ACTIVATED [PARKING SENSOR].)	Malfunction detection sound activates after ignition is switched ON and the selector lever (ATX)/Shift lever (MTX) is in the R position.
NO DETECTION SOUND/LOW VOLUME (See NO DETECTION SOUND/LOW VOLUME [PARKING SENSOR].)	The volume of the detection sound from the buzzer decreases/ the detection sound does not activate.